

# Salt & Pepper Shakers

## Supplies Needed

- 1" Forstner Drill Bit
- Blank
- Faceplate or Chuck
- Revolving Center
- Glue (Thick CA or Epoxy)
- Sandpaper/Finish
- Drill or Drill Press
- 4" x 4" Waste Block
- Eye and Ear Protection

## Steps

1. Select your blank and drill a 1" diameter hole 2 1/8" deep. Measure the shaker set for reference.
2. Mount a 4" x 4" waste block on a faceplate and turn a 1" diameter drive tenon 1" long. The blank should fit snugly over the drive tenon.
3. Mount the drilled blank onto the drive tenon and advance the tailstock with revolving center up against the bottom of the blank to provide pressure.
4. Turn to the desired shape, then sand and finish the blank.
5. The shaker set can be glued in place using an epoxy or bondaflex to allow for wood movement.

